# VISUAL INSTALLATION GUIDELINES FOR SLOAN





EBV-146-ACODE #0325176 - Closet<br/>CODE #0325177 - UrinalG2 MODULEREPLACEMENT

# Replacement of Optima Plus RESS Module to G2 Module EBV-146-A



MAGNET

2

TAPE

any

questions

2

### Removal of Optima Plus RESS Module

- **A.** With water supply and pressure turned off, remove Locking Ring by turning counterclockwise.
- B. Remove Outer Cover.
- C. Remove RESS Module.

3

С

#### G2 Module Preparation

- A. Remove tape and magnet entirely from Module. Start up Mode will activate (sensor flashes continuously).
- B. It is normal to find water inside bottom hole.

## A. Seat G2 Module onto Diaphragm Assembly.

Installation of G2 Module

- **B.** Seat Outer Cover over G2 Module.
- **C.** Install and tighten Locking Ring securely.



The information contained in this document is subject to change without notice.

- We recommend that you review our Royal G2 Optima Plus Installation Instructions and Maintenance Guides for complete instructions including Rough-in Dimensions, Specifications, Troubleshooting Guide, and Replacement Parts.
  - Call our Installation Engineers for additional information at 1-888-SLOAN-14 or fax them at 1-800-737-3061.

SLOAN.

SLOAN VALVE COMPANY • 10500 SEYMOUR AVENUE • FRANKLIN PARK, IL 60131 Phone: 1-800-9-VALVE-9 or 1-847-671-4300 • Fax: 1-800-447-8329 or 1-847-671-4380 • http://www.sloanvalve.com Copyright © 2007 Sloan Valve Company • Printed in the U.S.A. • Made in the U.S.A. • Module Replacement V.I.G. 0816482 — Rev. 0a (04/07)