

INDIVIDUAL PARTS		INDIVIDUAL PARTS		COMPOSITE PARTS	
T-1	Hot renewable seat	T-55C	Stop plaster shield removal tool	TA-4	Hot seat (T-1) Cold seat (T-3)
T-2	Cold seat O-ring	T-176	Plaster shield	TA-9	Cold seat O-ring (T-2) Hot washer screw (T-5) Hot washer (T-6) Cold washer retainer (T-7) Cold washer (T-8) Cap gasket (T-11)
T-3	Cold renewable seat	T-177	Wall mounting flange	TA-10	Spindle assembly
T-5	Hot washer screw	T3-27	Escutcheon (Model C) (2000 Series)	T3-31	Temperature control handle: Insert (T3-31 INS) Handle screw (T-32) Plug button (T3-33R)
T-6	Hot washer	T3-27B	Escutcheon gasket (2000 Series)	T3-31L	Loop style lever handle: Insert (T3-31 INS) Handle screw (T-32) Plug button (T3-33)
T-7	Cold washer retainer	T3-28	Escutcheon screw (2000 Series)	T3-31S	Solid style lever handle: Insert (T3-31 INS) Handle screw (T-32) Plug button (T3-33)
T-8	Cold washer	T3-29	Dial/emblem assembly (2000 Series)	RC-14X	Single blade lever handle: Handle screw (T-32) Plug button (T-33) Set screw (SC-15A)
TA-10	Flow control spindle	T3-29K	Dial		
T-11	Cap gasket	T3-31 INS	Handle insert		
T-12A	Cap assembly	COMPOSITE PARTS			
T-16	Packing, O-ring and washers	T-52	Stop spindle assembly/ escutcheon screw retainer (T-52A)		
T-17	Packing nut	T-65	Temperature control handle Handle screw (T-32) Plug button (T-33)		
T-19/20	Dome cover and lock nut	T-101	Acrylic handle: Handle screw (T-32) Plug button (T-33)		
T-27	Escutcheon (BP series)				
T-27B	Gasket (BP series)				
T-28	Escutcheon screws (BP series)				
T-29CT2	Dial (BP series)				
T-32	Handle screw with lock washer				
T-33	Plug button				
T-34	Limit stop with O-ring				
T-35A	Hot seat removal tool				
T-35B	Cold seat removal tool				
T-52A	Stop spindle assembly/ escutcheon screw retainer				
T-55B	Stop plaster shield				

FIGURE 9

Parts Breakdown

