

INDIVIDUAL PARTS		INDIVIDUAL PARTS		COMPOSITE PARTS	
SC-15A	Handle set screw	T-30	Diverter and/or volume handle	TA-4	Hot seat (T-1) Cold seat (T-3)
T-1	Hot renewable seat	T-32	Handle screw with lock washer	TA-9	Hot washer screw (T-5) Hot washer (T-6)
T-2	Cold seat O-ring	T-33	Plug button		Cold washer retainer (T-7) Cold washer (T-8)
T-3	Cold renewable seat	T-34	Limit stop with O-ring		Cap gasket (T-11)
T-5	Hot washer screw	T-35A	Hot seat removal tool	TA-10	Spindle assembly
T-6	Hot washer	T-35B	Cold seat removal tool	TA-25A	Diverter/volume spindle (T-23A) O-ring (T-24) for Model A tub/shower valve (beige or gray)
T-7	Cold washer retainer	T-52A	Stop spindle assembly/ escutcheon screw retainer	TA-25B	Volume spindle (T-23B) O-ring (T-24) for Model B shower valve (black)
T-8	Cold washer	T-55B	Stop plaster shield	T-31	Temperature control handle: Handle screw (T-32) Plug button (T-33R)
TA-10	Flow control spindle	T-55C	Stop plaster shield removal tool	T3-31L	Loop style lever handle: Insert (T-31 INS) Handle screw (T-32) Plug button (T-33)
T-11	Cap gasket	T-176	Plaster shield	T3-31S	Solid style lever handle: Insert (T-31 INS) Handle screw (T-32) Plug button (T-33)
T-12A	Cap assembly	T-177	Wall mounting flange		
T-16	Packing, O-ring and washer	T3-31 INS	Handle insert		
T-17	Packing nut	COMPOSITE PARTS			
T-19/20	Dome cover and lock nut	RC-14X	Single blade lever handle: Set screw (SC-15A)		
T-21C	Diverter retainer	T-52	Stop spindle assembly/ escutcheon screw retainer (T-52A)		
T-23A	Diverter spindle (Model A) (beige or gray)	T-101	Acrylic handle: Handle screw (T-32) Plug button (T-33)		
T-23B	Diverter spindle (Model B) (black)				
T-24	Spindle O-ring				
T-27	Escutcheon				
T-27CL	Diverter handle clip				
T-27B	Gasket				
T-28	Escutcheon screws				
T-29A	Dial (Model A)				
T-29B	Dial (Model B)				
T-29C	Dial (Model C)				

**FIGURE 9
Parts Breakdown**

